





- U. Liège: O. Absil, J. Surdej, S. Habraken, M. Van Droogenbroeck,
 D. Defrère, C. Delacroix, G. Orban de Xivry, M. Reggiani, O. Wertz,
 B. Carlomagno, V. Christiaens, C. Gomez Gonzalez, A. Jolivet
- U. Uppsala: M. Karlsson, P. Forsberg, P. Piron, E. Vargas Catalan
- Caltech/JPL: D. Mawet, E. Serabyn, K. Matthews, G. Ruane, AJ Riggs,
 E. Choquet, M. Bottom, H. Ngo, R. Jensen-Clem
- Obs. Paris: E. Huby, P. Baudoz
- + collaborators at ESO (J. Girard, J. Milli, M. Kasper, H.-U. Käufl),
 CEA Saclay (E. Pantin), U. Leiden (M. Kenworthy, F. Snik),
 Keck (B. Femenia, P. Wizinowich), U. Arizona (P. Hinz)

OLIVIER ABSIL

FIVE YEARS OF HARVEST WITH THE VORTEX CORONAGRAPH



OUTLINE

history and technology development commissioning & on-sky performance scientific results

image processing with machine learning future projects




HISTORY AND TECHNOLOGY DEVELOPMENT




THE BIRTH OF A CONCEPT

FQPM → sub-wavelength grating → annular groove phase mask




- advantages:
 - * inner working angle
 - * clear 360° discovery space
 - * achromaticity







THE VORTEX CORONAGRAPH IN A NUTSHELL



perfect on-axis cancellation for a circular aperture








IMPLEMENTATIONS OF THE VORTEX PHASE MASK

- scalar vortex
 - * helical piece of glass
- vector vortex
 - * liquid crystal polymers
 - * subwavelength gratings
 - * photonic crystals





Annular Groove Phase Mask






OPTIMIZING THE GRATING DESIGN







Delacroix et al. (2013)




MANUFACTURING DIAMOND AGPM @ UPPSALA

Vargas Catalan et al. (2016)

 diamond coated with Al and Si layers (sputtering) e-beam pattern transferred with solvent-assisted moulding


etching



3. reactive ion etching




SETTING UP THE « YACADIRE » BENCH @ MEUDON






ANGUISH...













BLISS!





BEST PERFORMANCE IN THE LAB - 2017 UPDATE


- bench (VODCA)
 now available at
 ULiège
- L-band AGPMs
 etched & tested
- broadband rejection up to 1500 : 1





EXTENDING THE CONCEPT

- AGPM first developed for thermal infrared (L, M, N bands)
 - * excellent performance on ~30% bandwidth
- manufacturing tests for H-K bands promising, but more work needed
- now exploring higher topological charges
 - * less sensitive to tip-tilt, at the expense of larger IWA



charge-4 vortex, work in progress




COMMISSIONING & ON-SKY PERFORMANCE



INSTALLATION AND COMMISSIONING

- piggyback on existing coronagraphic IR cameras
- very short commissioning phase (1-2 nights)












AGPM FIRST LIGHT @ NACO (DEC 2012)

worked out of the hox






Mawet et al. (2013)





ON-SKY OPERATIONS: THE VORTEX GLOWS!


- thermal emission outside pupil partly diffracted inside pupil by vortex
- seen in all instruments (vortex upstream cold stop)
- removed by background subtraction
- useful for centering





ON-SKY OPERATIONS: ACQUISITION & CENTERING

- pointing errors create asymmetric « donut »
- central obstruction changes the expected behavior of the donut




- need modeling to infer
 pointing error from image (QACITS algorithm)
- can be used to control pointing at low frequency



CLOSED-LOOP CENTERING CONTROL

- fully automated vortexoperations with QACITSvalidated on NIRC2
 - * includes acquisition & calibration
- ensures consistantcentering and data quality
- rms jitter ~ 0.02 λ/D (@ 0.03 Hz)








pupil after Lyot stop

ON-SKY STARLIGHT CANCELLATION @ NIRC2


- on-sky extinction limited by
 - * pupil geometry / Lyot stop
 - * AO residuals
 - * non-common path aberrations
- daytime speckle nulling helps reduce NCPA ... but NIRC2 upgrade needed!








Bottom et al. (in prep)









IMPROVEMENT IN DETECTION LIMITS @ NIRC2

- obvious gain in 3–10 λ/D region (0.25" 0.8")
- vortex reduces throughput @ 1-2 λ/D

saturated imaging

vortex imaging





comparison based on two HR 799 data sets with similar integration time and parallactic angle rotation, processed using a standard PCA-ADI algorithm



VORTEX PERFORMANCE ON VARIOUS INSTRUMENTS

